
Quick Installation Guide

USB Flash Drive

Introduction

The Flash Drive works as a friendly, secure, and lightweight removable mass storage device disk. It plugs through the USB port so your host computer will immediately detect and configure the removable drives without re-starting computer again.

Unlike most USB Flash disks, it also comes with a security feature that allows you to require a password upon plugging the disk before use. This USB Flash Drive is partitioned into a 1-Mbytes accessory disk and a main disk. Users have to enter the security password to gain access into the main disk. The 1MB accessory disk (no password) can also be used to preload the driver and utility program of the USB Flash drive.

CD Content

- ?? Company & Product
- ?? User's Manual
- ?? Driver

System Requirements

Apple Computer

?? iMac, G3, G4 or iBook with available USB port

?? OS 8.x through 9.x

PC

?? AMD or Intel Pentium 133 MHZ or better based computer

?? Available USB port

?? Windows 98, Windows ME, Windows 2000, Windows XP

Hardware Installation Summary

1. Windows 98 :

Windows will first install "USB Storage" and then install "Security"

2. Windows ME, Windows 2000 and Windows XP :

Windows will install "Security"

When installing "Security" , Windows will pop up a "JUPITER_Check Password 1.0.0.0" dialog box. Please don't key in password, just click on "**OK**" then "**More**" to exit.

After installation, you will find there are four addition devices at "Device Manager". That is "Generic USB Hub", "USB Security Device" and two "USB Mass Storage Device" .

Running the Utility Program

The utility program allows you to set the password and device name as well as disk format.

To run utility program:

1. Double-click on the **JUPITER.EXE** file program found on your CD.
2. enter the correct password and click "**OK**". Then click "**More**".

Function content on this utility:

1. Set/Check Password
2. Change Password
3. Clear Password (If you clear password then you are disabling the security function)
4. Change Device Name (This is useful if you have more than one USB disk and want to identify them)
5. Format

Uninstalling Flash Drive's Driver

Double click on "**RM2315.EXE**" and follow the easy steps to install.

Using Multiple Flash Drive

If in case you inserted two or more Flash Drive, both drives will be detected by the utility program . Run the utility program and click on the pull-down cursor of the device item. This will pull down the list of Flash Drive detected and heir device name.

Technical Support

If you encounter any technical problem, please contact us through:

Taiwan First Line Electronics Corp.

4F, No. 36-1, Huang Hsi Street, Shihlin Dis. Taipei, Taiwan, R.O.C.

Tel: 886-2-2837-8121; Fax: 886-2-2837-8198 or 2837-8199

Web site: www.bafo.com.tw

OR

Quality Computer Accessories Inc. NJ

70 Ethel Road West, Unit 1, Piscataway, NJ 08854, USA

Tel: 1-732-572-3338; Fax: 1-732-572-3009

Web site: www.bafo.com